



MORE POWER : LESS NOISE



Congratulations, you have purchased the finest exhaust system for your motorcycle on the market. Your Vance & Hines exhaust system is designed and crafted for maximum performance, a perfect fit, a great sound and unbeatable style. Please follow the installation instructions below and if you have any questions, please call our technical support line at (562) 926-5291.

Attention installer (if other than owner), please forward this instruction sheet to the owner of this product. These instructions contain valuable information to the end user.

TOOLS REQUIRED

- Flat blade screwdriver
- 5/16" Nutdriver
- 1/2", 9/16" & 7/8" or 22mm Combination wrenches
- 1/4", 3/16" & 5/16" Allen wrench
- Snapping pliers
- Ft./Lb. Torque wrench
- 3/8" Ratchet & Extensions, 1/2" Socket, 1/2", 9/16" & 5/8" deep sockets,

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

STOCK EXHAUST SYSTEM REMOVAL

1. Remove both left and right saddlebags and set them aside.
2. Loosen the bolt from the pinch clamp on the front end of each muffler.
3. Remove the two 5/16" bolts that mount the muffler to the saddlebag supports. Repeat this step on the opposite muffler.
4. Remove the stock mufflers and set them aside. NOTE: It may be necessary to use a penetrating lubricant to loosen the muffler from the head pipe.
5. Find and unplug the O2 sensor wires from the wiring harness and remove cable tie holding front wire to frame. Feed the end of the wires through the frame so they are free from the motorcycle. NOTE: Pay attention to wire routing for re-installation.
6. Remove the right hand floor board.
7. Remove the right hand passenger floor board.
8. Remove the section of head pipe connecting the left side muffler and the mount bracket on the backside of the oil pan.
9. Remove the rear head pipe clamp and mount clamp located behind the oil pan, set the 1/4"-20 x 3/4" screws aside for reuse.
10. Install the crosspipe support bracket (stamped 515-P)(supplied) at the stock location behind the oil pan with the stock 1/4"-20 x 3/4" screws (Figure 8). NOTE: Do not fully tighten at this time.
11. Loosen the nut and carriage bolt holding the front head pipe to the bracket on the transmission housing.
12. Loosen the heat shield clamps on both front and rear exhaust pipes.
13. Remove the two mounting nuts from each head pipe, located at the cylinder head. Carefully remove the head pipes and set them aside.
14. Using a 7/8" or 22mm wrench, carefully remove the O2 sensors from the stock head pipes and save for re-use with the new system.
15. Carefully remove the exhaust port flanges and circlips from the stock exhaust system using snapping pliers. NOTE: If circlips look bent or twisted, replace them.
16. Replace the bracket on the transmission housing with new bracket (stamped 514-P)(supplied) and torque to 13-16 ft. lbs. (Figure 1).
17. Carefully remove the stock exhaust gaskets, and replace them with the supplied exhaust gaskets.







FIGURE 5



Installing nutplate

FIGURE 6




Make sure pipes and heat shields run parallel

FIGURE 7



Install 515-P bracket, making sure that both brackets are aligned

FIGURE 8



VANCE & HINES EXHAUST SYSTEM INSTALLATION

- Remove head pipes and heat shields from protective packaging. Place each heat shield on a non-abrasive surface such as blanket or carpet. Using a felt tip pen, mark outside edge of each heat shield to show location of mounting clips that hose clamps will loop through (Figure 2).
- Lay head pipes into heat shields and loosely install the #20 hose clamps (supplied) into mounting clips (Figure 2). NOTE: Screw heads should be accessible when the system is installed on motorcycle for adjustment purposes (Figure 3). Do not tighten at this time.
- Apply a small amount of anti-seize compound to the threads of the O2 sensors and install them into the new head pipes. NOTE: Be careful not to get anti-seize on sensor tip, it may affect sensor function.
- Install circlips and flanges from stock system onto both new head pipes (Figure 4).
- Using stock flange nuts, carefully install head pipes onto motorcycle. Do not tighten at this time.
- Use the nut plates and 5/16" x 5/8" flange bolts (supplied) to attach the pipes to the bracket (Figure 5). Do not tighten at this time.
- Align pipes on motorcycle so the gap between the two heat shields is parallel where they run together (Figure 6). Tighten the exhaust port flange nuts and the 5/16" x 5/8" flange head bolts.
- Install the Torca Band Clamp (supplied), with the nut facing down, on the expanded end of the front head pipe (Figure 7).
- Carefully slip the end of D557FC crosspipe (supplied) into the expanded portion of the front head pipe and using the remaining nut plate and 5/16" x 5/8" flange head bolts (supplied) attach the pipe to the bracket. NOTE: The edges of the two brackets should be even.
- Install the mufflers of your choice onto both head pipes and secure with the stock 5/16" bolts and lock washers.
- Check alignment of mufflers and make corrections as required.
- Tighten the stock 1/4"-20 screws securing the bracket to the oil pan and flange head bolts securing the crosspipe to the bracket.
- Tighten the all band clamps securing the crosspipe and the mufflers to the head pipes
- Plug the O2 sensor wires back into the wiring harness and route wires away from hot areas of the motorcycle. Use the nylon cable tie (supplied) to secure the front O2 sensor wire to the frame.
- Install Spacer (593-P), on floor board support plate (Figure 8). Remove the left 3/8" socket cap screw only and place the spacer onto floor board support plate aligning the holes in the spacer with those on the support plate. Re-install the 3/8" socket cap screw into the original hole capturing spacer. NOTE: You may use the 3/8" stock socket cap screw to temporarily hold spacer alignment while tightening the 3/8" socket cap screw.
- Install a 3/8" lock washer (supplied) on the 3/8"-16 x 3" socket cap screw (supplied). Using this bolt re-install the floor board with ONE 1" spacing washer (supplied) (Figure 8) on the forward (right) mount. NOTE: Spacing washer are located between the floor board supports and floor board mount plate. On CVO Models, a 3/8"-16 x 1-1/2" socket cap screw (not supplied) should be used from the inside on the right mount rather than the 3/8"-16 x 3" provided bolt.
- Re-install the right side passenger floor board.
- Re-install the saddlebags.
- Be sure to tighten all hardware before starting your motorcycle.
- After installation and before starting the motorcycle, completely clean pipes and mufflers with cleaning solvent and a clean soft cloth that will not leave residue. NOTE: Any residue, oil, or fingerprints will stain the chrome when the metal heats up.

EXHAUST CARE - HELPFUL HINTS TO AVOID DISCOLORATION OF EXHAUST SYSTEM

- When installing a new set of chrome pipes, make sure your hands are clean and free of oil. After installation, thoroughly clean pipes with a soft cloth and cleaning solvent that will leave no residue (chrome wax / polish, glass cleaner, alcohol, ammonia, etc...) before starting the motorcycle.
- Avoid long periods of idling as this can cause discoloration.
- Intake leaks can cause the engine to run lean and overheat, this could lead to discoloration.
- Make sure there are no exhaust leaks at the junction of the exhaust pipes and cylinder head. We recommend replacing gaskets if they are worn.

VANCE & HINES OPTIONAL ACCESSORIES

FUELPAK



FUEL MANAGEMENT:

Take the guess work out of fuel injection with Fuelpak Fuel Management. Contact your local dealer or call (562) 921-0071 to order. Visit fuelpakfi.com for more information. Fuelpak is intended for racing or off-highway use only, and is not legal for sale or use in California on pollution-controlled vehicles.

PLEASE NOTE: Every effort is made for Vance & Hines Exhaust Systems to provide improved cornering clearance. However, due to design and space limitations on some motorcycle models, ground and cornering clearance may not be improved and in some cases may be reduced. Be sure to follow proper installation instructions.




PACKING LIST




Nylon Cable Tie x 1




3/8"-16 x 3.0" Socket Head Capscrew x 1




#20
Hose Clamps x 9




Torca Band Clamp x 1




Nut plate x 3




5/16" Flange Head
Bolt x 6




3/8" Lock Washer x 1



Exhaust Gasket x 2



1" x 3/16"
Washer x 1



593-P x 1

PARTS NOT SHOWN:

514-P	Mounting Bracket	x1
515-P	Mounting Bracket	x1
D555FC	Front Header Assembly	x1
D555HC	Front Heatshield	x1
D556FC	Rear Header Assembly	x1
D556HC	Rear Heatshield	x1
D557FC	Crosspipe Header Assembly	x1
D557HC	Crosspipe Heatshield	x1

MORE POWER : LESS NOISE

ALL PARTS SHOWN ARE ACTUAL SIZE

WARRANTY

Vance & Hines exhaust systems are warranted against defects in material and workmanship for a period of 90 days from the date of purchase from an authorized dealer. This warranty does not cover discoloration of chrome finishes. This warranty is limited to the repair or replacement of a product proven to be defective from normal use. Vance & Hines exhaust systems are designed to fit and operate on OEM motor and chassis. This warranty does not cover any product subject to abuse, misuse, improper installation or modification.

FUEL MANAGEMENT

GET THE MOST OUT OF YOUR RIDING EXPERIENCE...

AN AFTERMARKET EXHAUST SYSTEM IS ONLY YOUR FIRST STEP, NOW YOU NEED FUEL MANAGEMENT.

NOW YOU NEED FUELPAK.

Your fuel injected Harley-Davidson® is equipped with an ECU (electronic control unit) that's programmed to deliver fuel to the motor based on an air/fuel ratio for a stock air filter and stock exhaust system. When you install a performance exhaust system, your airflow changes, so you need a fuel management system that adjusts your air/fuel ratio to match the changes. That fuel management system is Fuelpak. Fuelpak adds and takes away fuel, allowing for a more precise range of refinement in your air/fuel ratio. Get the perfect fuel management combination with your Vance & Hines exhaust system, get Fuelpak. For more information visit the tuning center at fuelpakfi.com

NOTICE: Fuelpak is intended for racing or off-highway use only, and is not legal for sale or use in California on pollution-controlled vehicles.



MORE POWER : LESS NOISE

13861 ROSECRANS AVENUE / SANTA FE SPRINGS, CA 90670
SALES: (562) 921-5388 / TECHNICAL: (562) 926-5291 / FAX: (562) 802-0110
VANCEANDHINES.COM